




**BMW  
MOTORRAD**

**GETTING STARTED**  
**ConnectedRide Com U1**



**MAKE LIFE A RIDE**

**OVERVIEW**




**LEGEND**


- 1 Speaker connections
- 2 Status LED
- 3 Mesh Intercom aerial
- 4 Bluetooth aerial
- 5 Mesh Intercom button
- 6 Connection for USB-C charging and data cable
- 7 Button (-)
- 8 Middle button
- 9 Button (+)
- 10 Microphone connection

**FUNCTIONS**

**Switch on/off**




**Battery state of charge**



**Pairing**

TFT display, Navigator or mobile phone




## FUNCTIONS


### Adjust volume



### Mobile phone



### Pair Bluetooth Intercom






## FUNCTIONS

### Open Mesh Intercom


Switch Mesh Intercom on/off



Change Mesh channels






Activate/deactivate microphone



## AUDIO PLAYBACK

### Track



Consulting this Getting Started guide is not a substitute for careful and complete reading of the operating instructions and the safety information they contain. The guide accompanies the item of equipment. You can download the complete operating instructions from <http://bmw-motorrad.com/accessories-instructions>



Login @ My BMW Motorrad